

CHIOCCIOLE DI SCARICO - TURBINE HOUSINGS

Code	Part Name	Model	Turbo OE No
2100-011-G08B	Turbine Housings	B3G	5783-988-2200
2100-011-G19B	Turbine Housings	S200G	5770-988-2200
2100-011-G09B	Turbine Housings	B3G	5783-988-2201
2100-011-G17B	Turbine Housings	S200G	5774-988-2203
2100-011-G18B	Turbine Housings	S200G	5774-988-2204
2100-011-G11B	Turbine Housings	S200G	5774-988-2202
2100-011-G16B	Turbine Housings	S300G Variant	5780-988-2205
2100-011-G10B	Turbine Housings	S200G	5774-988-2201
2100-011-G02B	Turbine Housings	S200	5774-988-2200
2100-011-G01B	Turbine Housings	S300	5780-988-2200
2100-011-G12B	Turbine Housings	S300G	5780-988-2201
2100-011-032C	Turbine Housings	GT1749VA	758219-0002
2100-011-484	Turbine Housings	RHC6	GM-8
2100-011-649	Turbine Housings	KP35	5435-970-0019
2100-011-310	Turbine Housings	GT1544V	750030-0001
2100-011-001	Turbine Housings	GT1549S	452213-0003
2100-011-322	Turbine Housings	K03	5303-970-0055
2100-011-062	Turbine Housings	KP35	5435-970-0005
2100-011-373	Turbine Housings	BV39	5439-970-0030
2100-011-A01	Turbine Housings	RHF3	
2100-011-043	Turbine Housings	GT1549S	703245-0002
2100-011-034	Turbine Housings	GT2252V	454192-0001
2100-011-028	Turbine Housings	KP35	5435-970-0000
2100-011-085	Turbine Housings	BV39	5439-970-0027
2100-011-306B	Turbine Housings	GT2052V	454135-0009
2100-011-026	Turbine Housings	KP35	5435-970-0001
2100-011-542	Turbine Housings	TD025-03-06T	49173-02610
2100-011-002	Turbine Housings	K04	5304-970-0008
2100-011-990	Turbine Housings	GT1749V	801891-0002/801891-0001



Code	Part Name	Model	Turbo OE No
2100-011-385	Turbine Housings	GT1849V	717626-0001
2100-011-101	Turbine Housings	GT2260V	725364-0004
2100-011-117	Turbine Housings	GT1852V	718089-0005/6
2100-011-152	Turbine Housings	GT1752H	454061-0010
2100-011-122	Turbine Housings	GT1544S	454064-0001
2100-011-149	Turbine Housings	GT1549V	700447-0003
2100-011-519	Turbine Housings	TD025M-09T-3.3	49173-02401
2100-011-670	Turbine Housings	GT2056V	720931-0003
2100-011-526B	Turbine Housings	TF035HL2-12GK2-VGK	49135-02652
2100-011-032	Turbine Housings	GT1749VA	717858-0007/1
2100-011-032B	Turbine Housings	GT1749V(S1)	454231-0003
2100-011-301	Turbine Housings	GT1749V	708639-0002
2100-011-368	Turbine Housings	GT1849V	727477-0002
2100-011-044	Turbine Housings	TF035HM-12T-4	49135-04121
2100-011-331	Turbine Housings	K16	70000174636
2100-011-055	Turbine Housings	GT1544S	700830-0001
2100-011-795	Turbine Housings	K03	5303-970-0096
2100-011-030	Turbine Housings	GT1749V	454161-0001
2100-011-044B	Turbine Housings	TF035HM-12T-4	49135-02110
2100-011-218	Turbine Housings	CT VNT	17201-30010
2100-011-208	Turbine Housings	CT12B	17201-67010
2100-011-691	Turbine Housings	CT10	17201-30030
2100-011-316	Turbine Housings	GT2556V	454191-0009
2100-011-316B	Turbine Housings	GT2256V	704361-0004/5/6
2100-011-263	Turbine Housings	GT1749V	727210-0001
2100-011-444	Turbine Housings	GT1544V	782403-0001
2100-011-022	Turbine Housings	K14	5314-970-7018
2100-011-022B	Turbine Housings	K14	5314-970-7025
2100-011-128	Turbine Housings	TF035HM-12T	49135-03101
2100-011-359B	Turbine Housings	RHF4/VV14	VF40A132
2100-011-003	Turbine Housings	K03	5303-970-0029
2100-011-003B	Turbine Housings	K03	5303-970-0005



Code	Part Name	Model	Turbo OE No
2100-011-379	Turbine Housings	GT17	715924-0002
2100-011-527	Turbine Housings	TD025S2-06T4	49173-07507
2100-011-035	Turbine Housings	GT2052V	454205-0006
2100-011-306	Turbine Housings	GT2052V	454135-0005
2100-011-359	Turbine Housings	RHF4	VF40A132
2100-011-447	Turbine Housings	GT2052S	708257-5001
2100-011-303	Turbine Housings	GT1749V	750431-0006/750431-0009/50431-0012
2100-011-303C	Turbine Housings	GT1749V	717478-0001/2/3
2100-011-150	Turbine Housings	GT1752S	452204-0001/452204-0004
2100-011-612	Turbine Housings	GT2256V	724652-0001
2100-011-G17	Turbine Housings	S200G	5774-988-2203
2100-011-140B	Turbine Housings	GTP38	702011-5011
2100-011-232	Turbine Housings	TD04-09B-4	49177-01510
2100-011-038	Turbine Housings	GT1852V	709836-0001/709836-0003/709836-0004/726698-0003/2/1
2100-011-429	Turbine Housings	H1C	3526739
2100-011-G18	Turbine Housings	S200G	5774-988-2204
2100-011-039	Turbine Housings	GT2538C	454207-0001
2100-016-004	Turbine Housings	HT06	HT06
2100-016-014	Turbine Housings	HT06	HT06
2100-011-G10	Turbine Housings	S200G	5774-988-2201
2100-011-G08	Turbine Housings	B3G	5783-988-2200
2100-011-G09	Turbine Housings	B3G	5783-988-2201
2100-011-G19	Turbine Housings	S200G	5770-988-2200
2100-011-672	Turbine Housings	GT20	769708-5004
2100-011-G02	Turbine Housings	S200	5774-988-2200
2100-011-G12	Turbine Housings	S300G Variant	5780-988-2201
2100-011-052	Turbine Housings	K03	5303-970-0052/5303-970-0058
2100-011-140	Turbine Housings	GTP38	702011-5011
2100-011-G01	Turbine Housings	S300	5780-988-2200/5780-988-2205
2100-011-135	Turbine Housings	GT1749MV	755373-0001/755042-0002/767835-0001
2100-011-330D	Turbine Housings	GT1549V	454232-0009/1/3/4/5
2100-011-388	Turbine Housings	GT1749MV	766340-0001



Code	Part Name	Model	Turbo OE No
2100-011-107	Turbine Housings	GT1238S	712290-0001
2100-011-357	Turbine Housings	GT1749V	704226-0007
2100-011-033	Turbine Housings	KP39A	5439-970-0009
2100-011-748	Turbine Housings	GT1238S	727211-5001
2100-011-334	Turbine Housings	GT1544Z	706499-0001/706499-0004
2100-011-025	Turbine Housings	TF035HM-12T-4	49135-06015
2100-011-330	Turbine Housings	GT1749V	713672-0002
2100-011-330B	Turbine Housings	GT1749V	713673-0002
2100-011-330C	Turbine Housings	GT1749V	721021-0001
2100-011-353	Turbine Housings	GT1749V	724930-0006
2100-011-037	Turbine Housings	BV39	5439-970-0022
2100-011-221	Turbine Housings	GT2256MS	704136-5003S

CHIOCCIOLE DI COMPRESSIONE - COMPRESSOR HOUSINGS

JR NO	Part No	Model	Turbo OE NO
2200-011-001	Compressor Housings	GT1549S	452213-0003
2200-011-002	Compressor Housings	KO4	5304-970-0008
2200-011-003	Compressor Housings	K03	5303-970-0029
2200-011-011	Compressor Housings	K27	5327-970-6206
2200-011-022	Compressor Housings	K14	5314-970-7018
2200-011-025	Compressor Housings	TF035HM-12T-4	49135-06015
2200-011-026	Compressor Housings	KP35	5435-970-0001/5435-970-0009
2200-011-028	Compressor Housings	KP35	5435-970-0000
2200-011-030	Compressor Housings	GT1544V	454161-0001
2200-011-030C	Compressor Housings	GT1549V	701854-0002/3/4/713672-0002
2200-011-032	Compressor Housings	GT1749V(B1G)	717858-0001/717858-0007
2200-011-034	Compressor Housings	GT2252V	454192-0001
2200-011-034DB	Compressor Housings	GT2252V	454192-0001
2200-011-037	Compressor Housings	KP39A	5439-970-0009
2200-011-038	Compressor Housings	GT1852V	709836-0001/709836-0003/709836-0004
2200-011-039	Compressor Housings	GT2538C	454207-0001
2200-011-043	Compressor Housings	GT1549S	703245-0001/703245-0002



Code	Part Name	Model	Turbo OE No
2200-011-044	Compressor Housings	TF035HM-12T-4	49135-04121
2200-011-052	Compressor Housings	K03	5303-970-0052/5303-970-0058
2200-011-055	Compressor Housings	GT1544S	700830-0001
2200-011-062	Compressor Housings	KP35	5435-970-0005
2200-011-085	Compressor Housings	BV39	5439-970-0027
2200-011-101	Compressor Housings	GT2260V	742730-0001
2200-011-110	Compressor Housings	GT2052V	710415-0001
2200-011-116C	Compressor Housings	GT1546S	706978-0001
2200-011-117	Compressor Housings	GT1852V	718089-0005/6
2200-011-117DB	Compressor Housings	GT1852V	718089-0005/6
2200-011-122	Compressor Housings	GT1544S	454064-0001/454083-0001
2200-011-128	Compressor Housings	TF035HM-12T	49135-03101
2200-011-129	Compressor Housings	GT2052V	724639-0002
2200-011-129B	Compressor Housings	GT2052V	705954-0009
2200-011-140	Compressor Housings	GTP38	702011-5011
2200-011-149	Compressor Housings	GT1549V	700447-0003
2200-011-149B	Compressor Housings	GT1749V	708366-0001
2200-011-149DB	Compressor Housings	GT1549V	700447-0003
2200-011-150	Compressor Housings	GT1752S	452204-0001/452204-0004
2200-011-152	Compressor Housings	GT1552H	454061-0010
2200-011-155	Compressor Housings	T04B91	409410-0006
2200-011-181	Compressor Housings	GT1549S	720244-0001
2200-011-208	Compressor Housings	CT12B	17201-67010
2200-011-218	Compressor Housings	CT VNT	17201-30100
2200-011-221	Compressor Housings	GT2256MS	704136-5003S
2200-011-232B	Compressor Housings	TF035HM-12T-4	49135-02110
2200-011-249	Compressor Housings	RHC6	GM-6
2200-011-258	Compressor Housings	GT2260V	753392-0001
2200-011-263	Compressor Housings	GT1749V	727210-0001
2200-011-263DB	Compressor Housings	GT1749V	727210-0001
2200-011-300	Compressor Housings	K04	5304-970-0032
2200-011-301	Compressor Housings	GT1749V	708639-0002



Code	Part Name	Model	Turbo OE No
2200-011-303	Compressor Housings	GT1749V	750431-0006/750431-0009/750431-0012
2200-011-303DB	Compressor Housings	GT1749V	750431-0006/750431-0009/750431-0012
2200-011-305	Compressor Housings	GT1749V	712766-0001
2200-011-306	Compressor Housings	GT2052V (S1)	454135-0005
2200-011-306B	Compressor Housings	GT2052V	454205-0006
2200-011-306C	Compressor Housings	GT2052V(B1G)	454135-0009
2200-011-306DB	Compressor Housings	GT2052V (S1)	454135-0005
2200-011-306DD	Compressor Housings	GT2052V	454205-0006
2200-011-310	Compressor Housings	GT1544V	753420-0002
2200-011-310DB	Compressor Housings	GT1544V	753420-0002
2200-011-316	Compressor Housings	GT2556V	454191-0006
2200-011-316B	Compressor Housings	GT2256V	704361-0004/5/6
2200-011-316DB	Compressor Housings	GT2556V	454191-0006
2200-011-322	Compressor Housings	K03	5303-970-0055
2200-011-331	Compressor Housings	K16	70000174636
2200-011-334	Compressor Housings	GT1544Z	706499-0001/706499-0004
2200-011-340	Compressor Housings	TD025M-06T-2.3	49173-06500
2200-011-341	Compressor Housings	GT2256V	709838-0004/709838-0015
2200-011-350	Compressor Housings	GT1646V	765261-0005
2200-011-353	Compressor Housings	GT1749V	724930-0006
2200-011-353B	Compressor Housings	GT1749V	721021-0001
2200-011-357	Compressor Housings	GT1749V	714467-0008
2200-011-359	Compressor Housings	RHF4	VF40A132
2200-011-368	Compressor Housings	GT1849V	727477-0002
2200-011-368DB	Compressor Housings	GT1849V	727477-0002
2200-011-373	Compressor Housings	BV39	5439-970-0030
2200-011-379	Compressor Housings	GT17	715924-0002
2200-011-379B	Compressor Housings	GT1749S	715924-0001
2200-011-385	Compressor Housings	GT1849V	717626-0001
2200-011-388	Compressor Housings	GT1749MV	766340-0001
2200-011-388DB	Compressor Housings	GT1749MV	766340-0001
2200-011-389	Compressor Housings	GT16V	757886-0003



Code	Part Name	Model	Turbo OE No
2200-011-421	Compressor Housings	TF035	49135-02910
2200-011-427	Compressor Housings	TD03L4-07T-VG	49131-06007
2200-011-429	Compressor Housings	HIC	3526739
2200-011-433	Compressor Housings	GT1749MV	755373-0001
2200-011-433DB	Compressor Housings	GT1749MV	755373-0001
2200-011-441	Compressor Housings	BV35	5435-970-0014
2200-011-444	Compressor Housings	GT1544V	782403-0001
2200-011-444DB	Compressor Housings	GT1544V	782403-0001
2200-011-481	Compressor Housings	GTP38	702650-0005
2200-011-484	Compressor Housings	RHC6	GM-5
2200-011-519	Compressor Housings	TD025M-09T-3.3	49173-02401
2200-011-526	Compressor Housings	TF035HL2-12GK	49135-02652
2200-011-527	Compressor Housings	TD025S2-06T4	49173-07507
2200-011-542	Compressor Housings	TD025-03-06T	49173-02610
2200-011-612	Compressor Housings	GT2256V	724652-0001
2200-011-617	Compressor Housings	KP35	5435-970-0006
2200-011-617B	Compressor Housings	KP35	5435-970-0019
2200-011-641	Compressor Housings	BV43	5303-970-0122
2200-011-650	Compressor Housings	BV35	5435-970-0015
2200-011-670	Compressor Housings	GT2056V	720931-0003
2200-011-670DB	Compressor Housings	GT2056V	720931-0003
2200-011-672	Compressor Housings	GT20	769708-5004
2200-011-679B	Compressor Housings	HT12-22	
2200-011-691	Compressor Housings	CT10	17201-30030
2200-011-707	Compressor Housings	TD03L4	49590-45607
2200-011-707B	Compressor Housings	TD03L4	49590-45607
2200-011-743	Compressor Housings	TF035V	49135-07310
2200-011-795	Compressor Housings	K03	5303-970-0096
2200-011-920	Compressor Housings	RHF55/CIES	VB440031/VA440031
2200-011-971	Compressor Housings	GTA1849V	717625-0001
2200-011-980	Compressor Housings	RHF4H	4JA1T
2200-011-990	Compressor Housings	GT1749V	801891-0002/801891-0001



Code	Part Name	Model	Turbo OE No
2200-011-990DB	Compressor Housings	GT1749V	801891-0002/801891-0001
2200-011-992	Compressor Housings	GT1749V	713517-0012
2200-011-992DB	Compressor Housings	GT1749V	713517-0012
2200-011-G01	Compressor Housings	S300	5780-988-2200/5780-988-2205
2200-011-G02	Compressor Housings	S200	5774-988-2200
2200-011-G02B	Compressor Housings	S200G	5774-988-2205
2200-011-G08	Compressor Housings	B3G	5783-988-2200
2200-011-G08B	Compressor Housings	B3G	5783-988-3200
2200-011-G09	Compressor Housings	B3G	5783-988-2201
2200-011-G12	Compressor Housings	S300G	5780-988-2201
2200-011-G14	Compressor Housings	S300G	5780-988-2203
2200-011-G15	Compressor Housings	S300G	5780-988-2204
2200-011-G17	Compressor Housings	S200G	5774-988-2203
2200-011-G19	Compressor Housings	S200G	5770-988-2200

